

# Projector Start-up Guide

If you have problems with this system, Dial “O” or 4-2867 from the classroom phone.

While pointing the “Projector Remote Control” toward the projector,  
press the Power (RED) button.

(Wait 90seconds for the Projector warm-up.)

The “Projector Remote Control” is located on the White Board Tray.

## Computer Projection

Connect the 15-pin VGA cable and attached audio cable to the monitor and audio-out ports on your laptop.

Press the input button marked “COMPUTER” on the Remote Control and select “Computer 1”.

**(You should see the input displayed on the upper right corner of the screen)**

Be sure that your computer is set to display to two screens.

Use the volume “UP” and “Down” button on the Remote Control to set the sound level from the projector.

## To project from DVD/VCR or Other Video Sources

Turn on projector as above.

Connect your DVD/VCR etc. to the Video/Audio connections on the VGA wall plate using your standard video (yellow) and audio (red & white) VCR cables.

Press the “VIDEO” button on the Remote Control to select the “Video” input.

**(You should see the input displayed on the upper right corner of the image on the screen)**

Operate your external source in its normal fashion.

Use the volume “UP” and “Down” button on the Remote Control to set the sound level from the projector.

**This system cannot be used for Audio Only presentations.**

When Finished, Press the Power Button on the “Projector Remote Control” Twice  
(with a pause between each button push).

The projector should display a “Shutting Down” message.