

Smart Classroom Projection Quick Start Guide

Press the **“Projector On”** button on the SmartPanel Control **once (Wait 90sec for the warm-up).**

Press the **“Projector Off”** button on the SmartPanel before you leave the room.

If you have problems with this system, Dial **“O”** or 4-2867 from the classroom phone.

A: Computer Projection

- 1: The laptop can be placed onto the opened (lowered) DVD/VCR compartment if desired.
- 2: Connect one of the 15-pin VGA connectors to the monitor port on your laptop.
- 3: Press the button marked either “Computer 1 or 2” on the SmartPanel control (**1 for left cable or 2 for the right cable**).
- 4: Set your computer’s display resolution to a maximum of **1024x768**.
- 5: Adjust your laptop for either dual or external monitor support.
- 6: Connect your Ethernet cable to the jack next to the SmartPanel (if available).
- 7: Use the volume “UP” and “Down” buttons on the SmartPanel to control the sound in the room.
- 8: When finished, replace VGA/Audio cable on the hook provided below the connection panel.
(See your desktop support technician for more information on the settings needed for 4, 5 or 6.)

B: DVD or VCR Projection (Turn the player “off” when finished)

- 1: Open (Lower) the DVD/VCR compartment.
- 2: Press the “Power” button on the DVD/VCR machine to turn on the unit (left side).
- 3: Press the “DVD/VCR” button on the SmartPanel control.
- 4: Insert a DVD or a VHS tape into the unit.
- 5: Press the appropriate “VCR” or “DVD” button *on the attached remote control* to enable the appropriate function buttons.
- 6: Or, press the “Play” “REW” “FF” “Stop” buttons on the front of the DVD/VCR machine as needed. **Note:** For more advanced features (eg. Menu buttons), use the attached remote control.

C: Campus Cable TV Projection (Turn the player “off” when finished)

- 1: Open (Lower) the DVD/VCR compartment.
- 2: Press the “Power” button on the DVD/VCR machine to turn on the unit (left side).
- 3: Press the “DVD/VCR” button on the SmartPanel control.
- 4: Press the “VCR” button **on the attached remote control** to activate the channel tuner.
- 5: Using the remote control, select the appropriate campus cable channel by pressing the numbers on the number pad, (for example: 0 and 4 for channel 4,) or by pressing the up/down channel buttons. You can also use the up/down buttons on the Player to select a channel.
- 6: Use the volume “UP” and “Down” buttons on the SmartPanel to control the sound in the room.

D: Auxiliary Video Projection

- 1: Press the “Auxiliary Video” button on the SmartPanel.
- 2: Connect a video camera, or other video device to the inputs located next to the switching panel.

E: Audio Only Playback

- 1: Open (Lower) the DVD/VCR compartment.
- 2: Press the “Power” button on the DVD/VCR machine to turn on the unit (left side).
- 3: Load a CD into the DVD Player.
- 4: Press the Volume “up” button until the desired level is reached.
- 5: Turn the player “off” when finished and press the “projector off” button to turn off the system.