

DH 515 - Projector Start-up Guide

While pointing the “Projector Remote Control” toward the projector,
press the Power (RED) button.

(Wait 90seconds for the Projector warm-up.)

The “Projector Remote Control” is located on the center island.

Computer Projection

Connect the 15-pin VGA cable and attached audio cable to the monitor and audio-out ports on your laptop.

Press the input button marked “COMPUTER” on the Remote Control:

Select “Computer 1” input for Department equipment or

Select “Computer 2” input for wall mount connections.

(You should see the input displayed on the upper right corner of the screen)

Be sure that your computer is set to display to two screens.

For wall mount connections use the volume “UP” and “Down” button on the Remote Control to set the sound level from the projector.

To project from DVD/VCR or Other Video Sources

Turn on projector as above.

Connect your DVD/VCR etc. to the Video/Audio connections on the VGA wall plate using your standard video (yellow) and audio (red & white) VCR cables.

Press the “VIDEO” button on the Remote Control:

Select the “Video” input for Department equipment or

Select the “Component” input for wall-mount connections.

(You should see the input displayed on the upper right corner of the image on the screen)

Operate your external source in its normal fashion.

For wall mount connections use the volume “UP” and “Down” button on the Remote Control to set the sound level from the projector.

This system cannot be used for Audio Only presentations.

When Finished, Press the Power Button on the “Projector Remote Control” Twice

(with a pause between each button push).

The projector should display a “Shutting Down” message.